



# Assembly Instructions

## Norfolk Arbour

Code: 00505

V6 05 24




(W x D x H) 1.56m x 0.67m x 1.99m



**ONLINE ASSEMBLY VIDEO AVAILABLE**

Please scan the QR code or visit [zestoutdoorlivingsupport.co.uk](http://zestoutdoorlivingsupport.co.uk)



**PLEASE KEEP THESE INSTRUCTIONS**

## Every Zest product is unique because each piece of timber has its own distinctive, natural features



Zest is a leading timber specialist, designing and manufacturing award winning wooden garden products, crafted from natural slow-grown European redwood. Unlike man-made materials, timber is an entirely natural material, and each piece has its own distinctive qualities. So, owning a Zest timber product is like enjoying a unique slice of nature.



The benefits of slow grown timber:

“Trees grow slowly in the cold climate of Eastern Europe producing stronger and close grained timber ideal for making quality outdoor products.”

## Natural and Unique



There may be variations in the timber's colour or shading, but these will fade away over time when exposed to sunlight.



The changing seasons in each year of growth create characteristics unique to each tree - and to every piece of timber. Branches create an embedded mark in the tree trunk, resulting in a knot. Knots are a unique and natural feature which tells the story of the tree.



Owing to timber's natural moisture content, variations in temperature and humidity can cause expansion and contraction and may result in cracks and splits in any product made from natural timber. Any cracks and splits in the timber grain will alter with the changing seasons. They do not compromise the strength and durability of the product - they just add to its unique character.



Most Zest products are pressure treated which protects the timber from rot for many years. Pressure treatment can result in a small amount of 'green spotting' on the surface of new timber caused by natural salts leaving the wood. This will fade away over time.

These visible changes are not a fault or a cause for concern and do not affect the structural integrity of the product. They are a result of how the timber matures and responds to its natural environment.

### Ethically Sourced

Zest's slow grown European redwood is sourced from responsibly managed PEFC certified forests. This means forests are used in a way that maintains biodiversity, regeneration, and nature conservation. PEFC tracks certified timber from the forest to the final product giving complete confidence to the customer. [www.pefc.co.uk](http://www.pefc.co.uk)



### Replanting

Zest with its main supply partners is dedicated to replanting woodland and is collaborating on the nurture of wildlife habitats.

### Advisory Notices

- Roofs are weather resistant and not guaranteed to be watertight unless otherwise stated.
- Items with enclosed storage or cupboard space are weather resistant and are not watertight unless otherwise stated.
- Be aware of trap hazards if a Zest product has moving parts.
- All products should be positioned on solid, level ground
- Anchor down products where applicable using appropriate fixings.
- Roofs are not weight bearing
- Sanitise all catering surfaces prior to use.

# Norfolk Arbour Assembly Instructions

Requires 2 Person assembly


Tools required: Corded/Cordless Drill, \*Pozi-drive bit/Screwdriver (\*Crosshead), 3mm drill bit. (All screw holes to be pre-drilled)

We advise the product is situated on firm level ground and anchored to the ground or wall with suitable fixings (not supplied).

Please take a few moments to check all pack contents listed


Norfolk Arbour Pack List			
Code	Item	Description	Quantity
09211	A	Side Panel	2
09212	B	Front Panel	1
09213	C	Rectangular Trellis Panel	1
09214	D	Back Panel	2
09215	E	Base Panel	1
09216	F	Lid/Seat Assembly	1
09217	G	Seat Back Assembly	1
09218	H	Fascia	4
09219	J	Roof Panel	2
09221	K	Finial	2
09220	L	Roof Capping	2
09223	M	Triangular Trellis Panel	1

10487 - Norfolk Arbour Fixings List		
Item	Description	Quantity
1	40mm Screws	11
2	50mm Screws	16
3	60mm Screws	30



This product is made from pressure-treated timber. It should not be painted or coated with any other treatment until at least 6 months after purchase

1





Place Front Panel B between battens on Side Panels (A) (flush with outer edge of battens) and fix through Side Panels (A) using 4 x 60mm screws (2 x Screws per side).

2




Position Rectangular Trellis Panel (C) to rear posts of Side Panels (A) (flush with back and top of posts) and fix using 4 x 60mm screws (2 x per side).

3




Place 1 x Back Panel (D) directly beneath Rectangular Trellis Panel (C) and fix through posts using 4 x 60mm screws (2 x Screws per side). Place remaining Back Panel (D) beneath fixed Back Panel (D) and attach through posts using 4 x 60mm screws (2 x Screws per side).

4





Insert Base Panel (E) and fix using 4 x 40mm screws (1 x Screw per corner).

5





Position Lid/Seat Assembly (F) (lipped lid edge to front) onto upper battens of side panels and fix as shown using 4 x 60mm screws (2 x Screws per side).

6



Place Seat Back Assembly (G) onto fixed section of Lid/Seat Assembly (F) and fix in position using 4 x 60mm screws (2 x Screws per side).

7



Using Triangular Trellis Panel (M) as a guide, set out Roof Panels (J) and 2 x Fascia's (H) as shown.  
**Note: Ensure roof board overlaps are in correct orientation as to avoid rainwater ingress.**

Attach Fascia's (H) to Roof Panels (J) using 6 x 50mm Screws (3 x Screws per Fascia).

8



Fix 1 x Finial (K) to Fascia's (H) using 2 x 50mm Screws.  
**Repeat Stage 8 for remaining Fascia's (H) and Finial (K) on other side of Roof Panels (J).**

9



Join 2 x Roof Capping's (L) using 3 x 40mm Screws and attach to Roof Panels (J) using 4 x 40mm Screws (2 x Screws per end).

10



Fix Triangular Trellis Panel (M) to Rectangular Trellis Panel (C) using 2 x 60mm Screws.



Place roof assembly on to Side Panels (A) and Triangular Trellis Panel (M). Fix in position through Fascia's (H), into Side Panels (A) using 4 x 60mm Screws. (1 x Screw per Fascia (K)).

**Norfolk Arbour is now complete.**